

MobiRake 2000 Wireless Backhaul OFDM-TDMA 5GHz lite Outdoor Subscriber

User Manual

Includes install, configuration and trouble shooting information for the broadband wireless access outdoor radio.

Version 2.0.1



Copyright

Copyright © 2007 all rights reserved. No part of this publication may be reproduced, adapted, stored in a retrieval system, translated into any language, or transmitted in any form or by any means without the written permission of the supplier.

About This Manual

This manual includes install, configuration and trouble shooting for the 5GHz Lite outdoor subscriber. It can help you in avoiding the unforeseen problems and use the outdoor radio correctly.

Technical Support

If you have difficulty resolving the problem while installing or using the wireless bridge, Please contact the supplier for support.

Table of Contents

| | |
|--|-----------|
| CONVENTIONS | 4 |
| CHAPTER 1 INTRODUCTION | 5 |
| 1-1 FEATURES AND BENEFITS | 5 |
| CHAPTER 2 HARDWARE INSTALLATION | 7 |
| 2-1 PRODUCT KIT | 8 |
| 2-2 SYSTEM REQUIREMENTS | 8 |
| 2-3 MECHANICAL DESCRIPTION | 9 |
| 2-4 HARDWARE INSTALLATION | 12 |
| CHAPTER 3 CONFIGURATION | 14 |
| 3-1 START-UP AND LOG IN | 14 |
| 3-2 WIRELESS SETUP | 16 |
| 3-4 MANAGEMENT | 21 |
| APPENDIX A: TROUBLE SHOOTING | 26 |
| GENERAL DESCRIPTIONS | 26 |
| CONNECTION ISSUES | 27 |
| CONFIGURATION ISSUES | 27 |

Conventions

This publication uses the following conventions to convey instructions and information:



This symbol means *reader take note*. Notes contain helpful suggestions or references to materials not contained in this manual.



This symbol means *reader be careful*. In this situation, you might do something that could result in equipment damage or loss of data.



This warning symbol means *danger*. You are in a situation that could cause bodily injury. Before you work on any equipment, be aware of the hazards involved with electrical circuitry and be familiar with standard practices for preventing accidents.

Chapter 1 Introduction

With highly-powered OFDM-TDMA technology, this outdoor lite-subscriber is a high capacity point-to-point backhaul for 5GHz ISM band wireless deployment in long distance. 5/10/20/40 MHz adjustable channel bandwidth provides the flexibility of deployment channel plan or high capacity backhaul -- truly throughput up to 50Mbps.

It utilizes Time Division Duplex technology allowing operation on a single channel with different uplink / downlink ratio. This improves the efficiency of channel BW usage rate. The Ethernet products are primarily designed to provide standard Ethernet interface in a wireless link between distant sites.

This lite-subscriber has powerful security management because it supports WEP-128bits, AES-256 bits encryption, and use the proprietary protocol. All these functions make the network much more secure and reliable.

1-1 Features and Benefits

■ Effective spectrum utility / variable capacities

This radio has 4 kinds of channel bandwidths (5/10/20/40 MHz) for optional, which is adjustable via software. This function provides flexibilities of channel plan and variable capacities for different applications.

■ OFDM-TDMA technology improves the performance in long distance

This radio improves the throughput performance up to 50~70% in long distance due to the better efficiency of OFDM-TDMA technology, that means the system has the same performance with lower EIRP (smaller antenna) compare to other standard wifi products.

■ Time-Division Multiplexing Access technique

TDMA tech can avoid the packets collision and send the packets more efficient and stable to improve the quality of wireless transmission in long distance.

■ High output power OFDM technology and Integrated antenna

Integrated panel antenna type with the high output power OFDM technology provides best performance and lowest price at the same time support this radio to be the most cost effective solution in the long distance wireless backhaul market.

■ Proprietary Security

This radio uses proprietary protocol, which means other standard wifi products can't connect to this radio. It also provides WEP-128bits and AES-256bits encryption to build the highest security mechanism to prevent the malicious attacking from the internet.

■ Antenna Alignment (Audible antenna alignment)

The site survey function provides the RSSI (signal strength) info to indicate the status of antenna alignment. The radio also supports audible antenna alignment for aligning the antenna by the earphone of your mp3 player, quite easy and simple.

■ FETURES

- Provides the easy installation and high performance outdoor PTP / PTMP wireless backhaul up to 20 KM.
- With a data rate up to 5.5Mbps / 10Mbps / 20Mbps / 40Mbps (with different bandwidth: 5MHz / 10MHz / 20MHz / 40MHz), customer can select the suitable bandwidth via the software.
- Technique operating in the 5GHz.
- Integrated 18dBi panel antenna.
- Transmit Power Control :

Supports settable transmit power levels to adjust coverage cell size, ranging from full, half(50%), quarter(25%) eighth(12.5%) and min
- Provides WEP-128 bits AES-256 bits as well as MAC access control to increase security.
- Provides Web-based configuration utility, user friendly interface.
- Support SNMP (Simple Network Management Protocol) for management.
- IP-68 rated weather-proof housing

Chapter 2 Hardware Installation

This chapter describes initial setup of the lite outdoor subscriber.

Warnings



Do not work on the system or connect or disconnect cables during periods of lightning activity.



Ultimate disposal of this product should be handled according to all national laws and regulations.



Only trained and qualified personnel should be allowed to install, replace, or service this equipment.



To meet regulatory restrictions, the radio and the external antenna must be professionally installed. The network administrator or other IT professional responsible for installing and configuring the unit is a suitable professional installer. Following installation, access to the unit should be password protected by the network administrator to maintain regulatory compliance.



The 5GHz Lite outdoor subscriber and POE injector can be damaged by incorrect power application. Read and carefully follow the installation instructions before connecting the system to its power source.



Follow the guidelines in this chapter to ensure correct operation and safe use of the ISM band radio.

2-1 Product Kit

Before installation, make sure that you the following items:

| | |
|--|-----|
| ◆ 5GHz TDMA Lite outdoor subscriber..... | x 1 |
| ◆ Power over Ethernet..... | x 1 |
| ◆ Power Adapter..... | x 1 |
| ◆ Power Cord..... | x 1 |
| ◆ Mounting kit..... | x 1 |
| ◆ Product CD..... | x 1 |
| ◆ Quick Installation Guide..... | x 1 |

NOTE: If any of the above items are missing or damaged, please contact your local dealer for support.

2-2 System Requirements

Before installing the 5GHz Lite outdoor subscriber, please make sure that these equipments have been met:

- A 10/100 Mbps Local Area Network device such as a hub or switch. (optional)
- Category 5 UTP or STP networking cable. (From the PC to POE)
- Category 5 SSTP or SFTP networking cable. (From the radio to POE)
- A Web browser for configuration: Microsoft IE 5.0 or later, or Netscape Navigator 5.0 or later version.
- Installing TCP/IP protocol to the computer.

2-3 Mechanical Description

Please refer to the following table for the meaning of each feature.

MECHANICAL DESCRIPTION

Please refer to the following table for the meaning of each feature.





Lite Outdoor subscriber Figure

| | | |
|----------|-------------------|--|
| 1 | RJ-45 Port | Use the SFTP or UTP cat.5 cable with weatherproof connector to connect to the "To ODU" side of the POE injector. |
|----------|-------------------|--|

POE


24VDC POE



Power Over Ethernet Injector Figure

| | | |
|---|---------------|---|
| 1 | To Ethernet | This RJ-45 port is used to connect to the 10/100 Base T complied device such as switch, router or PC. |
| 2 | To ODU | This RJ-45 port is used to connect to the ODU. |
| 3 | DC Input | Connect to the Power adaptor for DC input. |
| 4 | LED Indicator | Power LED |

+/- 48VDC POE (optional solution)



Power Over Ethernet Injector Figure

| | | |
|----------|----------------------------|---|
| 1 | To Ethernet | This RJ-45 port is used to connect to the 10/100 Base T complied device such as switch, router or PC. |
| 2 | To ODU | This RJ-45 port is used to connect to the ODU. |
| 3 | DC 48V | Connect to the +/- 48V DC source |
| 4 | LED Indicator (PWR) | Power LED |
| 5 | Grounding stud | Connect to the ground conductor with the ground wire. |


2-4 Hardware Installation

The 5GHz Lite outdoor subscriber is a radio device, so it is susceptible to common causes of interference that can reduce throughput and range. Follow these basic guidelines to ensure the best possible performance:

- IF there is any other 5GHz RF device deployed around the outdoor radio, try to set the channel to the non-overlapping one.
- Install the bridge at a height sufficient place where structures, trees, or hills do not obstruct radio signals to and from the unit. A clear line-of-sight path can guarantee the performance of the RF link.

■ Site Surveys

Clear and flat area provide better RF range and data rate, on the contrary, physical obstructions such as trees, electric tower, hills or buildings can reduce the performance of RF devices. Do not deploy your radios in the location where there is any obstacle between the antennas.





Configure and verify the 5GHz Lite outdoor subscriber operations first before you mount the radio in a remote location.




Power Over Ethernet Injector is not a waterproof unit, should not be exposed to outdoor without any protection.

Chapter 3 Configuration

3-1 Start-up and Log in

In order to configure the long distance backhaul, use the web browser and please do the following:

1. Type the IP address **http://192.168.1.1** of this radio in the Location (for IE) or Address field and press Enter.
2. Enter the system name (the default setting is “**admin**”) and password (the default setting is “**password**”).
3. Click on the “**Login**” button.



After you have logged-in the main page, the **About**, **Basic Setup**, **Wireless Setup**, **Status**, **Statistics**, **Management** and **Logout** buttons will be shown. The main menu provides links to the whole sections of the web configuration interface.

About

The About screen describes the product information briefly. Information of the radio includes **Device Name**, **MAC Address**, and **Firmware Version information**.

| Device Information | |
|--------------------|-------------------|
| Device Name | DEVICE000867 |
| MAC Address | 00:1b:5c:00:08:67 |

| Firmware | |
|------------|--------------------------|
| Version | 1.22 |
| Checksum | f0f25363 |
| Build Time | Fri Apr 15 17:46:05 2011 |

Basic Setup / IP Setup

The screenshot shows the 'IP Settings' configuration page for a Hyperable MobiRake device. On the left is a navigation menu with options: About, Basic Setup, IP Setup (highlighted), STP Setup, Statistics, Wireless Setup, Management, and Logout. The main content area is titled 'IP Settings' and contains the following fields:

- Device Name:** A text input field containing 'DEVICE000868'.
- Ethernet Data Rate:** A dropdown menu currently set to 'Automatic'.
- VLAN(802.1Q):** Radio buttons for 'Enable' and 'Disable', with 'Disable' selected.
- Management VLAN ID:** A text input field containing '0'.
- IP Address:** Radio buttons for 'Manual' and 'DHCP', with 'Manual' selected.
- IP Address:** A text input field containing '192.168.1.1'.
- IP Subnet Mask:** A text input field containing '255.255.255.0'.
- Default Gateway:** A text input field containing '0.0.0.0'.
- Primary DNS Server:** A text input field containing '0.0.0.0'.
- Secondary DNS Server:** A text input field containing '0.0.0.0'.

At the bottom of the form are 'Apply' and 'Cancel' buttons.

The **Device Name** is used to give a name to your TDMA outdoor radio. This will enable you to manage your Wireless backhaul more easily if you have multiple radios on your network.

Ethernet Data Rate: you can choose the Ethernet data rate you need

A dropdown menu showing three options: 'Automatic' (highlighted in blue), 'T-base10Mbps', and 'T-base100Mbps'.

VLAN (802.1Q): enable this feature and assign a management Vlan ID to the radio. Those PC without same Vlan ID will not be allowed to connect this radio and configure it.

IP Address: Type the IP address you want to set to your TDMA outdoor radio (Default: 192.168.1.1).

IP Subnet Mask: The Wireless backhaul's Subnet Mask must be the same as your Ethernet network. We recommended that you do NOT change the value. (Default: 255.255.255.0).

Default Gateway: The Wireless backhaul will use this value for default Gateway.

Primary DNS Server: The Wireless backhaul will use this value for primary Domain Name Server.

Secondary DNS Server: The Wireless backhaul will use this value for secondary Domain Name Server.

Basic Setup / STP Setup

Spanning tree protocol (STP): You may Enable or Disable the Spanning Tree Protocol used in this radio.

Spanning Tree Protocol Settings

Spanning Tree Protocol (STP) ☒ Enable ☐ Disable

Bridge Priority (0-65535)

Hello Time (1-10) seconds

Max Age (6-40) seconds

Forward Delay (2-30) seconds

Advanced

Wireless Node Aging (15-600) seconds

Note: If you complete the settings, please click on “Apply” for changes to take effect.

3-2 Wireless Setup

Wireless Setup / Radio Settings

Radio Settings

Radio Frequency (RF) ☒ Enable ☐ Disable

Operating Mode

Group Name

Time Slot (10 - 100) ms

Upload Stream Time Ratio (20 - 80) %

Basic Parameters

RF Bandwidth

Channel / Frequency

TX Rate Range -

TX Power

Fragmentation Length (276-2346) ☒ Auto

Radio Frequency (RF): You can enable/disable the RF interface.

Group Name: Base station and CPEs in same network must have the same Group name.

Operating Mode:

Base Station : The default mode is Base Station.

CPE : Perform as a client station associated to other APs. Be sure that they share the same SSID when connected.

Time Slot: Time slot divide using time between every client, default is 10ms. (only available in base station mode)

Upload Stream Time Ratio: Decide upload (CPE to BS) packets time ratio of every time slot, default is 50%. (only available in base station mode)

Only Base Station: Set the MAC of base station, this CPE can only connect to the base station with this MAC address. (Only available in CPE mode)

RF Bandwidth: Decide bandwidth of Radio Frequency. Including 5 / 10 / 20 / 40 MHz, default is 20MHz.

Channel / Frequency: Set the operation frequency of the radio.

TX Rate Range: Normally choice transmission rate as “Best”, system will adapt best rate for real environment.

Including:

64QAM 3/4, (54Mbps)
64QAM 2/3, (48Mbps)
16QAM 3/4, (36Mbps)
16QAM 1/2, (24Mbps)
QPSK 3/4, (18Mbps)
QPSK 1/2, (12Mbps)
BPSK 3/4, (9Mbps)
BPSK 1/2, (6Mbps)

TX Power :

Setting power of TX, default is Full

Half = full - 3 dBm


Quarter = full - 6 dBm

Eighth = full - 9 dBm

Min = full -12 dBm

Fragmentation packet length:

Decide the length of the maximum fragmentation packet. When packet is large than setting, it would divide to smaller segment package. By default, it will divide the length of segment packet automatic



Security/Cipher To prevent unauthorized radios from accessing data transmitted over the link, the Encryption Settings window offers WEP/AES features, making your data transmission over air more secure and allows you to specify Encryption Key(s) if you enable encryption for the radio. There are three degrees of encryption could be selected: **NONE, 128 bits WEP and 256 bits AES.**

Security/Cipher Phrase After you select the encryption, please key-in the same phrase in this field of the both radios (local and remote) and then press apply, radio will generate a password automatically.

Flow control Flow control is the process of managing the rate of data transmission

between two nodes to prevent a fast sender from outrunning a slow receiver. It provides a mechanism for the receiver to control the transmission speed, so that the receiving node is not overwhelmed with data from transmitting node.

Status / Connections

The connections page provides below information: **Time**, **MAC Address** (remote radio), **IP Address** (remote radio), **channel info** (RF bandwidth / frequency), **Rx rate**, **Tx rate**, **RSSI**, **remote RSSI** and **Best Remote RSSI**.

| ID | MAC Address | IP Address | RSSI | Rx Rate | Remote RSSI | Tx Rate |
|----|-------------------|-------------|--------|-----------|-------------|-----------|
| 2 | 00:1b:5c:00:08:68 | 192.168.1.1 | -45dBm | 64QAM 3/4 | -44dBm | 64QAM 3/4 |

Statistics

The Statistics screen provides various Ethernet and Wireless TX/RX packet statistics. Click the **Refresh** button to update the statistics on this screen.

Hyperxable
MobiRake

About
Basic Setup
Statistics
Wireless Setup
Management
Logout

Statistics

Ethernet Statistic

| | Received | Transmitted |
|---------|----------|-------------|
| Packets | 1930 | 2206 |
| Bytes | 243774 | 416314 |

Wireless Statistic


| | Received | Transmitted |
|-------------------|----------|-------------|
| Unicast Packets | 510 | 513725 |
| Broadcast Packets | 270 | 0 |
| Multicast Packets | 472 | 0 |
| Total Packets | 1744 | 513725 |
| Total Bytes | 182901 | 30403911 |

Refresh

3-4 Management

Management / Change Password

This page allow you to change password of the TDMA outdoor radio.



The screenshot shows the Hyperable MobiRake web interface. On the left is a navigation menu with the following items: About, Basic Setup, Wireless Setup, Status, Statistics, Management, Change Password (highlighted), Remote Management, Upgrade Firmware, Backup/Restore, Time Setting, Event Log, Reboot, and Logout. The main content area displays the 'Change Password' form. The form has three input fields: 'Current Password', 'New Password', and 'Repeat New Password'. Below these fields is a 'Restore Default Password' section with radio buttons for 'Yes' and 'No' (the 'No' option is selected). At the bottom of the form are 'Apply' and 'Cancel' buttons.


1. Key in the current password in the “Current Password” filed. Default password of this radio is “password”
2. Key in the new password to the New Password field, and then type it again into the Repeat New password field to confirm the new password.
3. Click the “Apply” button to active the settings.
4. You can restore to default password too by check the “yes” option.

Note: After you change password, please take note of your new password. Otherwise, you will not able to access the radio with correct password.

Management / Upgrade Firmware

The Upgrade Firmware menu will display the Upgrade Firmware page, you can update the latest firmware to the TDMA outdoor radio.

Please make sure that you are using the latest and correct firmware before you doing the upgrade procedure.




Below are the upgrade procedures:

- Using browser to access the main page of the TDMA outdoor radio
 1. Select "Upgrade Firmware" from the **Management** page.
 2. Input the exact file path and name or select the file by clicking **Browse** button, then press **Upload** button to upgrade the firmware.
 3. Please wait for few seconds.
- If download fail, please repeat the step 1~3 to download again.

Note! Do not power off the unit when it is being upgraded.

Management / Backup / Restore Settings

The current system settings can be saved into a file as a backup by clicking "**Backup**". The saved file can be loaded back on the radio by clicking "**Browse**". When you have selected the settings file, click "**Retrieve**" to begin the process. Furthermore, you may click "**Restore**" to factory default settings.



Management / Time Setting

The current system settings can be saved into a file as a backup by clicking “**Backup**”. The saved file can be loaded back on the radio by clicking “**Browse**”. When you have selected the settings file, click “**Retrieve**” to begin the process. Furthermore, you may click “**Restore**” to factory default settings.

Time: While you connect this Wireless backhaul to Internet, it could automatically synchronize the current time with the Time Server that you have set.

Time Server: the central time of the Time Server.

Time Server Port: the port of the Time Server.

Time Zone: You may select the appropriate local time zone for your radio from a list of all available time zones. Default: GMT.

Hyperable
MobiRake

Time Setting

Time

Time Server

Time Server Port

Time Zone

☐ Adjust for Daylight Saving Time

Current Time Wed May 12 04:29:00 2010

Apply Cancel

(GMT-12:00) International Date Line West
 (GMT-11:00) Midway Island, Samoa
 (GMT-10:00) Hawaii
 (GMT-09:00) Alaska
 (GMT-08:00) Pacific Time (US & Canada); Tijuana
 (GMT-07:00) Arizona
 (GMT-07:00) Chihuahua, La Paz, Mazatlan
 (GMT-07:00) Mountain Time (US & Canada)
 (GMT-06:00) Central America
 (GMT-06:00) Central Time (US & Canada)
 (GMT-06:00) Guadalajara, Mexico City, Monterrey
 (GMT-06:00) Saskatchewan
 (GMT-05:00) Bogota, Lima, Quito
 (GMT-05:00) Eastern Time (US & Canada)
 (GMT-05:00) Indiana (East)
 (GMT-04:00) Atlantic Time (Canada)
 (GMT-04:00) Caracas, La Paz
 (GMT-04:00) Santiago
 (GMT-03:30) Newfoundland
 (GMT-03:00) Brasilia
 (GMT-03:00) Buenos Aires, Georgetown
 (GMT-03:00) Greenland
 (GMT-02:00) Mid-Atlantic
 (GMT-01:00) Azores
 (GMT-01:00) Cape Verde Is.
 (GMT) Casablanca, Monrovia
 (GMT) Greenwich Mean Time: Dublin, Edinburgh, Lisbon, London
 (GMT+01:00) Amsterdam, Berlin, Bern, Rome, Stockholm, Vienna
 (GMT+01:00) Belgrade, Bratislava, Budapest, Ljubljana, Prague
 (GMT+01:00) Brussels, Copenhagen, Madrid, Paris

Management / Event Log

Hyperable
MobiRake

- About
- Basic Setup
- Wireless Setup
- Status
- Statistics
- Management
 - Change Password
 - Remote Management
 - Upgrade Firmware
 - Backup/Restore
 - Time Setting
 - Event Log**
 - Reboot
- Logout

Event Log

☐ **Enable SysLog**

Syslog Server IP Address:

Syslog Server Port Number:


Event Log Window

```

Wed May 12 04:13:23 2010 WLAN0: AP 00:1B:5C:00:06:8F associated.
Wed May 12 04:13:23 2010 WLAN0: AP 00:1B:5C:00:06:8F disassociated.
Wed May 12 04:13:17 2010 WLAN0: AP 00:1B:5C:00:06:8F associated.
Wed May 12 04:13:15 2010 WLAN0: 00:1B:5C:00:06:90 is ready in service.
Wed May 12 04:13:15 2010 WLAN0: 00:1B:5C:00:06:90 stop service.
Wed May 12 04:13:11 2010 WLAN0: 00:1B:5C:00:06:90 is ready in service.
Wed May 12 04:13:11 2010 WLAN0: 00:1B:5C:00:06:90 stop service.
Wed May 12 04:13:11 2010 WLAN0: 00:1B:5C:00:06:90 is ready in service.
  
```


Enable SysLog if you have a Syslog Server on your network environment. If enable, you need to input the Syslog Server IP Address (default is 0.0.0.0) and the port number your Syslog Server is configured to use. The default port number is 514. The Event Log Window lists Wireless backhaul events. Click on “Refresh” to update the network events or “Save As...” to save the event into a file on your computer. Click “Apply” if you made any changes.


Management / Reboot



The Reboot screen enables you to reboot your TDMA outdoor radio if any changes are made and you want to refresh the radio, you need to reboot the TDMA outdoor radio. Select the “**Yes**” check box and click “**Apply**”. It will take you about 50 seconds to go through reboot. The Web-browser will not be accessible until the Wireless backhaul has finished its reboot process.

Management / Logout

Click log out when you finished all the configuration, if there is anything missed, you can selected “login again” to enter the configuration process again.



Appendix A: Trouble shooting

This Appendix helps you to isolate and solve the problems with the 5GHz TDMA lite outdoor subscriber. Before you start troubleshooting, it is important that you have checked the details in the product user manual and QIG.

In some cases, rebooting the unit clears the problem. If the radio still can't work well, please try to contact your local vendor or supplier.

General Descriptions

To successfully use the radios, engineers must be able to troubleshoot the system effectively. This section will show you how an 5GHz TDMA outdoor radio could be analyzed in the case of "no link," usually, we think that the link is down because there is no traffic being passed. The four main reasons that a link may not work are listed as below:

- Configuration
- Path issues (such as distance, obstacles, RF reflection...)
- Personal reasons (careless mounting or the incorrect connection.)
- Hardware (includes the radio, cable and connectors...etc. In few cases, the radio will conflict with the laptop or PC)
- Environment (anything that is outside the equipment and not part of the path itself)

After verified the correct configuration, double-checked the path terms, ensure no personal reasons and the hardware works well in the office, but the user still report that the link does not work. Most likely, the problem reported is caused by the environment or by improper tests to verify the connection. Assumes that the test method, cabling, antennas, and antenna alignment have been checked, (Always ensure this before checking the environment.) then you can do the follow to check the environment.

General Check

Two general checks are recommended before taking any action:

- Check whether the software version at both sides is the most current
- Check for any reported alarm messages in the Event Log

Analyzing the Spectrum

The best way to discover if there is a source of interference is to use the spectrum analyzer. By turning the antenna 360 degrees, you can find out which direction is the interference coming from. It will also show the frequencies and the level of signal is detected.

Avoiding Interference

When a source of interference is identified and when the level and frequencies are known, the next step is to avoid the interference. Some of the following actions can be tried:

- Change the RF channel to the one away from the interference source

- Change the polarization of the antenna; try to change to a polarization different from the interferer.
- A small beam antenna may help. (Such as some grid or dish antenna, align the antenna in to the particular direction will reduce the affects from the interference source) This solution cannot help when the source of interference is right behind the remote site.

Before checking for interference, ensure all the hardware works well and configurations are correct. The path analysis, cabling and antennas should be checked as well.

Connection Issues

This section describes several common troubles the customer might have while setting the radios.

Radio Does Not Boot

When the Radio does not Boot, do the following steps to check your whole system:

1. Ensure that the power supply is properly working and correctly connected.
2. Ensure that all cables are workable and connected correctly.
3. Check the power source.

Cannot use the Web Interface

If the radio boot, but can't enter it via the Web site.

1. Open a command prompt window and enter **ping <ip address unit>** (for example: **ping 192.168.1.1**). If there is no response from the radio, make sure that you the IP address is correct. If there is response, the Ethernet connection is working properly, do the next step.
2. Make sure that you are using one of the following Web browsers:
 - Microsoft Internet Explorer version 5.0 or later
3. Ensure that you are not using a proxy server for the connection with your Web browser.

Double-check the physical network connections (includes the cables and the connectors). Use a well-known unit to ensure the network connection is properly functioning.

Configuration Issues

The following problems relate to setup and configuration problems.

Some basic configurations might make the link fail, below are the major ones:

- RF Channel
- Group name
- IP address
- Rule of MAC address filter
- Rule of security settings (such as WEP or WPA)

If the links of the two radios works within close distance of each other, then there are two possible reasons why wireless connectivity is not possible while the 5GHz TDMA outdoor radios are at their desired locations:

- RF path, for example, a bad antenna alignment, the tower is not tall enough when the radios are installed in a long distance or the connector do not attachment well...etc (these are the most common problems in installations)
- Interference problem caused by a high signal level from another unit. The interference can be checked by changing the frequency and then see if another channel works better. Or you can change the polarization of the antenna as a way of avoiding the interfering signal. To know in advance how much interference is present in a given environment, a Spectrum Analyzer can be attached to a (temporary) antenna for measuring the signal levels on all available Channels.



If the link still not works after resetting the configurations, checking the connectors and cables, double-check the path and environment issues, then the problem is possible a hardware problem. Acquiring a third radio and then testing it amongst the existing units will help to find out the broken unit.



Please contact your local vendor for advance technical support.
